

SETUP VESTA cameras



VESTA®



CAMERA STARTUP



STEP 1: INSEK POWER CABLE




STEP 2: WAIT FOR THE LED TO REMAIN FIXED IN GREEN (ETHERNET CONNECTION) OR FLASHING IN CASE OF WIFI SETUP.


SETUP FROM SMARTHOMESEC



Use SmartHomeSec to **initialise** the camera and **add** it to the system



STEP 1: Login to SmartHomeSec




STEP 2: Chose → Cameras → Add [+]




STEP 3: Chose → VESTA



STEP 4: Scan camera QR code




STEP 5: Select next



STEP 6: Chose communication of camera

SETUP FROM SMARTHOMESEC




STEP 7: Allow the APP to connect to a network on request



STEP 8: Select your WIFI network to which the camera will connect.




STEP 9: Enter WIFI password



STEP 10: Select IP of camera detected




STEP 11:
User name: *admin*
Password:
(Verification code of camera, label below)



SETUP COMPLETED

SETUP COMPLETED



I cannot find the IP of the camera on setup steps:

1. Ensure that the VESTA central controller is connected to the same network as the camera.
2. Restart the switch or router where the VESTA panel & Camera is connected.

I cannot complete the setup via WIFI

1. Check that you have the latest firmware in the VESTA control unit.
2. Make sure you give the APP permissions to connect to a WIFI network, and if it asks for connection permissions allow them.

The camera is not ready:

1. Reset camera to factory settings